

KROMALASER

FIRMWARE UPGRADE PROCEDURES

INSTRUCTION MANUAL



You need the Kromalaser Firmware Updater to upgrade the software within the:

- KROMALASER KONTROL 3d-EVO
- KROMALASER KL 3d-PRO
- KROMALASER KL 3d-1000

KROMALASER KONTROL 3d-EVO AND KL 3d -PRO UPGRADE PROCEDURE

Press the RED Power button, keep pressed and insert power supply plug.

The Red STATUS led will flash fast

Launch the Kromalaser Firmware Updater software on your Windows PC

Connect the USB to your PC.

The RED icon on the Kromalaser Firmware Updater software will turn to GREEN

Press “upgrade” and select the last firmware upgrade that Kromalaser sent you

The firmware will be loaded into your machine. DO NOT INTERRUPT LOADING YOU COULD NOT BE ABLE TO TURN ON THE 3D-EVO AGAIN

At the end of upgrade, you'll get a message from the PC.

After upgrade, disconnect the USB and restart the 3d-EVO

Check new software version on the 3d-EVO start splash screen.

KROMALASER KL 3d-1000 UPGRADE PROCEDURE

Press the footswitch #1 button, keep pressed and press the POWER button, turning on the machine

The Red STATUS led will flash fast

Launch the Kromalaser Firmware Updater software on your Windows PC

Connect the USB to your PC.

The RED icon on the Kromalaser Firmware Updater software will turn to GREEN

Press “upgrade” and select the last firmware upgrade that Kromalaser sent you

The firmware will be loaded into your machine. DO NOT INTERRUPT LOADING YOU COULD NOT BE ABLE TO TURN ON THE 3D-EVO AGAIN

At the end of upgrade, you'll get a message from the PC.

After upgrade, disconnect the USB and restart the KL 3d-1000

Check new software version with the KROMALASER MANAGER software