

Swivel Joint Female-Top
(Printed part)

Thread in Ball Joint
(From Tie Rod End Kit)

1 1/2" PVC Pipe
Cut to 13 3/4"

1 1/2" PVC Tee

Swivel Joint Male
(Printed Part)

Place Ball Detent
Flat Side up in
end of Tee

Install Pipe Assembly using Pipe
Clamps. Pipe Clamps may have
to be bent to fit properly

4 1/4"

