



Drill arm holes to clear 6/32 screw; typically 1/8".

Power Distribution Board holes are drilled to suit.

Tip: All the holes are on the lines of an 'X'.

After cutting the piece to size, draw an 'X' corner-to-corner on the plate.

For more information on Civilian UAVs
Visit www.dronespeak.com

Wide Body Multirotor Plate 2
Doug Starwalt 30 JUN 2013