



OUT  
-  
+

IN  
+

Voltage  
measured on  
the OUTPUT

CURRENT  
METER

VOLTAGE  
METER

CEN-TECH  
Meter #1  
  
Current Meter  
Set to 10 Amps DC

CEN-TECH  
Meter #2  
  
Current Meter  
Set to 20 VDC

## REAR VIEW of METERS

**PROBES**  
If used the following rules must be obeyed:  
..... There MUST BE NO connections to the INPUT and/or OUTPUT wires  
THEN  
.....connect both VOM+PROBE+ and VOM-PROBE- to the Volt meter (the left one) ONLY  
The VOLTAGE meter can be used as a normal VQOM meter, using the probes.

If there are ANY connections to either of the INPUT and OUTPUT wires  
THEN  
..... YOU MUST NOT, REPEAT NOT USE THE PROBES  
You risk shorting the power supply lines. Big bangs, smoke, destruction, you get the picture!

Released under the Creative Commons  
Attribution Share-Alike 4.0 License  
<https://creativecommons.org/licenses/by-sa/4.0/>

TITLE: Watthour Meter 2 Centech

Design by: **Steve Morse KI6HGH** REV:

Date: not saved! Sheet: 1/1