KRYLON SPRAYDOWN
Stories of REAL PERFORMANCE

# METALLIC WORKBENCH



Turn your old workbench into a work station with the help of Krylon® Rust Protector™ Metal Finish – Satin Nickel and Rust Protector™ Gloss Enamel – White.

## PROJECT TIME

2 hours

## SKILL LEVEL

1 **2** 3 4 5

## MATERIALS

- Krylon® Rust Protector™ Metallic Finish Satin Nickel
- Krylon® Rust Protector™ Gloss Enamel White
- Drop cloth
- All-purpose cleaner
- Rag
- Tack cloth
- Sandpaper or wire brush (optional)
- Painter's tape
- Cardboard or paper for masking

## INSTRUCTIONS

1. Set up a spray area by covering work area with a drop cloth. Make sure it is a well-ventilated area.
2. Using an all-purpose cleaner/degreaser, wipe down the entire workbench to remove all dirt and grime. Rinse thoroughly with water and allow to dry.
3. Prep surface by sanding any rough areas. If there are areas with flaking rust, use a wire brush to remove it. Wipe clean.
4. Applying in a well-ventilated area, begin painting the top work surface of the workbench, holding the can of Krylon Rust Protector Gloss Enamel – White 6-8 inches from the surface and paint using a sweeping side-to-side motion with slight overlap.

*(continued on next page)*

KRYLON SPRAYDOWN
Stories of REAL PERFORMANCE

## METALLIC WORKBENCH



Turn your old workbench into a work station with the help of Krylon® Rust Protector™ Metal Finish – Satin Nickel and Rust Protector™ Gloss Enamel – White.

## PROJECT TIME

2 hours

## SKILL LEVEL

1 **2** 3 4 5

## INSTRUCTIONS

5. Allow paint to dry for 30-60 seconds.
6. Continue to apply light, multiple coats, waiting 30-60 seconds between each, until you are satisfied with the appearance.
7. Allow paint to dry, less than one hour, and cover top work surface area with paper and painter's tape to mask.
8. Begin painting at the top of the metal workbench sides and legs, holding the can of Rust Protector Metallic Finish – Satin Nickel 6-8 inches from the surface, and paint using a sweeping side-to-side motion with slight overlap.
9. Allow paint to dry for 30-60 seconds.

*(continued on next page)*

KRYLON SPRAYDOWN
Stories of REAL PERFORMANCE

## METALLIC WORKBENCH



Turn your old workbench into a work station with the help of Krylon® Rust Protector™ Metal Finish – Satin Nickel and Rust Protector™ Gloss Enamel – White.

## PROJECT TIME

2 hours

## SKILL LEVEL

1 **2** 3 4 5

## INSTRUCTIONS

10. Continue to apply light, multiple coats, waiting 30-60 seconds between each, until you are satisfied with the appearance.

11. Krylon Rust Protector dries in 8 minutes or less, and can be handled in less than one hour.

12. Once fully dried, remove painter's tape and paper masking from top work surface area.